
How to use the AllBox

To call a resident

1. Touch anywhere on the screen to begin



2. Touch Directory




How to use the AllBox Page 1 of 5

3. Touch Directory search at the top of the screen



- 4. Start tying the residents name
- 5. When you see the resident you wish to visit, touch their name
- 6. A screen will pop up, confirming who you are calling
- 7. Tap the green button with the telephone icon



8. You will now be calling the resident. When they pick up, state your name. The resident should then press 9 on their phone to allow you access through the gate


How to use the AllBox Page 2 of 5

## To scan a pass

1. Touch anywhere on the screen to begin



## 2. Touch Visitor Access




How to use the AllBox Page 3 of 5

3. Scan the QR code from the pass on your phone, by holding your phone with the QR code facing the small square in the bottom middle of the AllBox.



- 4. If your pass is unable to be read, type the pass number into the keypad on the screen
- 5. Touch Enter




How to use the AllBox Page 4 of 5

## FAQs:

What is a QR code and how do I get one?

A QR code is a type of matrix barcode. The resident can send a visitor a QR code from the TEKControl portal by entering a visitor and clicking Save and Send ePass.

Sample of text (SMS) QR code.



How to use the AllBox Page 5 of 5